

standaard opbouw

TARTA Contour

4 wervels

	small TS4C S4A		medium TM4C M4A		large TL4C L4A		extra large TXL4C XL4A	
	rib	pads	rib	pads	rib	pads	rib	pads
	S1	053 062 053	M1	054 062 054	L2	054 062 054	X1	055 062 055
	S4		M4		L4		X4	
	S2	059 051 059	M3	060 051 060	L3	060 051 060	X3	061 051 061
	S1		M2		L2		X2	

5 wervels

	small TS5C S5A		medium TM5C M5A		large TL5C L5A		extra large TXL5C XL5A	
	rib	pads	rib	pads	rib	pads	rib	pads
	S1	053 062 053	M1	054 062 054	L2	054 062 054	X2	055 062 055
	S4		M4		L5		X5	
	S2	051 051 051	M2	051 051 051	L2	051 051 051	X2	051 051 051
	S2	059 052 059	M3	060 052 060	L4	060 052 060	X4	061 052 061
	S1		M2		L3		X2	


6 wervels

	small TS6C S6A		medium TM6C M6A		large TL6C L6A		extra large TXL6C XL6A	
	rib	pads	rib	pads	rib	pads	rib	pads
	S1	053 062 053	M1	054 062 054	L2	054 062 054	X1	055 062 055
	S4		M4		L5		X5	
	S2	056 056 056	M2	057 057 057	L2	057 057 057	X2	058 058 058
	S1	052 052 052	M3	052 052 052	L3	052 052 052	X3	052 052 052
	S3	059 059 059	M3	060 060 060	L4	060 060 060	X4	061 061 061
	S2	051 051 051	M2	051 051 051	L3	051 051 051	X2	051 051 051

overzicht

TARTA Pads

pads centraal



pads hoog



pads tussenliggend



pads laag

